

Bed Rack Offset Bracket Installation

1. This kit allows the mounting of accessories on the inside of RCI Bed Racks. Brackets are the exact same height as the bed rack cross-members allowing accessories to clear the crossmember rails. Great for installing traction boards or Rotopax on the inside of 18" tall racks.
2. Install brackets using 2 carriage bolts and secure with washers, lock-washers, and hex nuts. Third mounting hole is simply to provide mounting versatility for different locations on the bed rack.

Included Hardware Kit

| | | |
|----|-------------------------|-------|
| A. | 3/8" X 1" Carriage Bolt | 4 ea. |
| B. | 3/8" Washer | 4 ea. |
| C. | 3/8" Lock-washer | 4 ea. |
| D. | 3/8" Hex Nut | 4 ea. |



Disclaimer: The products sold by RCI Metalworks are intended for off-road use only, should not be modified, and are for use only on the vehicle(s) specifically stated. RCI Metalworks makes no warranties express or implied, including of fitness for a particular purpose or merchantability. RCI Metalworks will not be liable for any damages arising out of the use or misuse of its products. It is the customers' responsibility to ensure the products are safely and properly attached to the vehicle, and all products should be installed by trained professionals. We strive to maintain extremely high quality standards; however, all RCI Metalworks products are individually handcrafted, may vary slightly, and may contain minor imperfections. Due to the nature of raw aluminum, the material may have minor scratches and other blemishes caused by the manufacturing process, especially on the back side of product. RCI Metalworks is constantly seeking to improve its products and reserves the right to make changes to any product.